

T-Scale

Technical Manual

IHB++ Series



Precision Balance


REV:M1, JUne 2014

CONTENTS

| | |
|--|----|
| 1. PRECAUTIONS..... | 2 |
| 2. INTRODUCTION..... | 3 |
| 3. SPECIFICATIONS..... | 4 |
| 3.1 Dimension..... | 4 |
| 3.2 Specifications..... | 4 |
| 4. INSTALLATION..... | 6 |
| 5. DESCRIPTION..... | 8 |
| 6. OPERATION..... | 10 |
| 6.1 Power ON/OFF..... | 10 |
| 6.2 Zero..... | 10 |
| 6.3 Tare..... | 10 |
| 6.4 Weighing Unit | 10 |
| 6.5 Percent Weighing..... | 11 |
| 6.6 Parts Counting..... | 11 |
| 6.7 Accumulation..... | 12 |
| 7. PARAMETER..... | 13 |
| 8. CALIBRATION..... | 15 |
| 8.1 Linear Calibration..... | 15 |
| 8.2 Normal Calibration..... | 16 |
| 8.3 Manual Calibration by built-in weight..... | 16 |
| 8.4 Check internal Counts..... | 16 |
| 9. RS232 OUTPUT..... | 17 |
| 9.1 Specifications..... | 17 |
| 9.2 Continuously output protocol..... | 17 |
| 9.3 Print Format..... | 17 |

1. PRECAUTIONS

| | |
|---|--|
|  |  WARNING |
| | DISCONNECT ALL POWER TO THIS UNIT BEFORE INSTALLING, CLEANING, OR SERVICING. FAILURE TO DO SO COULD RESULT IN BODILY HARM OR DAMAGE THE UNIT. |

| |
|--|
|  CAUTION |
| <ul style="list-style-type: none">• Permit only qualified persons to service the instrument• Before connecting or disconnecting any components, remove the power.• Failure to observe these precautions bodily harm or damage to or destruction of the equipment. |

- The weighing scale is a precision electronic instrument, handle it carefully.
- Do not install the scale in direct sunlight.
- Verify the local voltage and receptacle type are correct for the scale.
- Only use original adaptor, other could cause damage to the scale.
- Pluggable equipment must be installed near an easily accessible socket outlet.
- Avoid unstable power sources. Do not use near large users of electricity such as welding equipment or large motors.
- Avoid sudden temperature changes, vibration, wind and water.
- Avoid heavy RF noise.
- Keep the scale clean


2. INTRODUCTION

- The IHB++ series balance, that amplifies signals from a load cell, converts it to digital data and displays it as a mass value.
- It is accurate, fast and versatile series of general purpose balances with counting, % weighing functions and accumulation
- 16.5 mm LCD with white LED back light display
- Battery provide up to 40 hours of continues use (with out backlight)
- Capacity 300g and 3000g.
- All units include automatic zero tracking, tare, and an accumulation facility that allows the count to be stored and recalled as an accumulated total

3. SPECIFICATION



3.1 Dimension



3.2 Specifications

| IHB++ SERIES | | |
|------------------|---|-------------|
| Model # | IHB++ -300 | IHB++ -3000 |
| Maximum Capacity | 300g | 3000g |
| Readability | 0.001g | 0.01g |
| Resolution | 1/300,000 | 1/300,000 |
| Tare range | -299.999g | -2999.99g |
| Minimum Capacity | 0.02g | 0.2g |
| Linearity ± | 0.003g | 0.01g |
| Platter | Φ 80mm | Φ 120mm |
| Wind shield | Yes | Yes |
| Units of Measure | g. / ct / lb / oz / d / gn / ozt / dwt / mom / tIT / tlh / tlj / t / bt / n | |

| Common Specifications | |
|------------------------------|---|
| Interface | RS-232 Output Optional |
| Stabilisation Time | 2 Seconds typical |
| Operating Temperature | 5°C - 40°C / 41°F - 104°F |
| Power supply (external) | 12V/500mA or built-in rechargeable battery 6V/1.2Ah |
| Calibration | Automatic External |
| ADC | Σ - Δ |
| Display | 16.5 mm high 6 digits LCD with auto backlight and loading bar graph |
| Balance Housing | ABS Plastic, Stainless Steel platform |
| Pan Size | Φ 80mm / Φ 120mm |
| Overall Dimensions (wxdxh) | 220mm x 340mm x 321mm |
| Other Features and Specs | accuracy enhancement for parts counting and percentage weight function |

4. INSTALLATION

Unpacking

Carefully take the balance out of its package, make it sure its not damaged and all accessories are included.

- Remove the weighing scale from the carton.
- Remove the protective covering. Store the packaging and to use if you need to transport the scale later.
- Inspect the scale and terminal for damage.
- Make sure all components are included


Accessories,

1. Balance
2. Adaptor
3. Pan
4. Product manual

Level Adjusting

Place the scale on a table.

Check the water mark. If, bubble is not centre adjust the leveling feet until reach centre. Check the level when you change the location.




Charging Battery

- To charge the battery insert the adaptor pin to jack, jack is locating rear side of the scale. Adaptor simply plug into the mains power. The scale no needs to be turned on.
- The battery should be charged for 12 hours for full capacity.
- Left side of the display there is an LED to indicate the status of battery charging. When the scale is plugged into the mains power the internal battery will be recharged. If the LED is green, the battery has a full charge. If it is red, the battery is nearly discharged and if yellow, the battery is being charged.
- Do not use any other type of power adaptor than the one supplied with the scale.
- Verify that the AC power socket outlet is properly protected.

Note: Please charge the battery before using the scale for the first time

Installation











- Place the scale on a table..
- Connect the adaptor pin in to the scale adaptor jack. Adaptor jack is locating, rear side of the scale.
- Adaptor connects into your AC power socket. Pluggable equipment must be installed near an easily accessible socket outlet with a protective ground/ earth contact.
- Turn on the On/Off key. If you want to turn off, press the key again.
- Display will be show the version number and will be starting self checking.
- After self checking, display will be come to normal weighing mode.
- **Warm-up time of 15 minutes stabilizes the measured values after switching on.**
- Calibrate with exact calibration weights, minimum 1/3 of the scale capacity want to use for calibration. For calibration, see details in parameter.

Then you can start your operation


5. DESCRIPTION

Key Board



| | |
|---|----------------------------------|
|  | Turns the scale power On / Off |
|  | Sets display to Zero |
|  | Subtracts weight of container |
|  | Set percentage weighing function |
|  | Set to counting mode |
|  | Set to weighing units |
|  | Set to print the results |

Display



| DISPLAY | FUNCTION |
|---------|---|
| | Indicator for Zero display |
| | Indicator for Tare display |
| | Indicator for weighing capacity graph |
| NET | Indicator for Net weight |
| | Indicator for Display stability |
| Pcs | Indicator for piece counting |
| mom kg | Indicator for units |
| % | Indicator for Percent weighing |
| | Indicator for Charging status of battery Voltage has dropped |
| | Low Voltage |
| | Fully Charged |

6. OPERATION

Initial Start-up

Warm-up time of 15 minutes stabilizes the measured values after switching on.


6.1 Power ON/OFF

Switch on the scale by pressing . The display is switched on and the self test is started.


If you want to switch off press the key again.



6.2 Zero

Environmental conditions can lead to the balance exactly zero in spite of the pan not taking any strain. However, you can set the display of your balance to


zero any time by pressing  key and therefore ensure that the weighing starts at zero.

6.3 Tare

The weight of any container can be tared by pressing  button so that with subsequent weighing the net weight of the object being weighed is always displayed.

- Load weight on the pan.
- Press  key. Zero is displayed, and tare is subtracted.
- Remove weight from the platform. Tared weight is displayed. It can set only one tare value. It can display with a minus value.
- Press  key. Zero is displayed, tare weight is cleared.


6.4 Weighing Unit

Press  key in the weighing mode to change the Weighing unit: g / ct / lb / oz / d / ozt / dwt / mom / tl.T / tlj / t / bt / n

6.5 Percent Weighing


The scale can set a sample weight to be shown as 100%. Then any other weights placed on the scale, it will be displayed as a percentage of the original sample.


For example:

- 350g weight placed on the scale and followed by pressing the  key is pressed the display will show 100.00%.
- Remove the weight, and ensure display is zero
- Place 300g weight on the platform, display will show 85.71 % as per the percentage of 350g (100%)
- The weighing may be amended on the basis of greater numbers of samples, improves the accuracy of percentage large quantities.

6.6 Parts Counting


Parts Counting

Press  key enter the parts counting mode and select the counting options

by pressing .

Display will be shown

| | | |
|-----------|------------|----------------|
| sp | 10 | For 10 pieces |
| sP | 20 | For 20 pieces |
| sP | 50 | For 50 pieces |
| sP | 100 | For 100 pieces |
| sP | 200 | For 200 pieces |


Select the counting option and press  to confirm.


Then can add more weight display will show the number of parts.

Parts Counting Operation


If necessary place a container on the platform and press  to make zero.

- Select the parts quantity as per the option
- Place the load on the platform

- Press  key to confirm, display will be shown ---- then will show the quantity
- Then can add goods on the platform, display will update the parts quantity automatically

Press  key to change normal mode, when in counting mode.



6.7 Accumulation

The scale can be set to accumulate manually by pressing  key.

Before operation scale should be stable and return to zero, accumulation available only when weight more than 20d

To enable accumulation function, select parameter **F4 ACC > ACC on**

Accumulation Operation

- Place the load on the platform.
- Press  key, when displayed STABLE indication.
- Display will be show  then will be show the total saved value. These displays will be shown only three seconds. If the optional RS-232 interface is installed the weight data will be send to printer.
- Remove the weight from the pan.
- When display get zero and stable then place the second weight.
- It can continue until the memory gets fully.

6.7.1 Memory Recall



To recall the memory press  key.

Display will be show

 **Acc X**


(X: Total number of accumulation) then will be show the total saved value. These displays will be shown only three seconds.

6.7.2. Memory Clear


To clear the memory, press  key to view and press  key during the accumulation displayed. Display will be show normal display , all accumulation memory cleared from the memory

7. PARAMETERS


Enter the Menu

- Turn on the scale. Press  during that start up until display will be shown F1 unt

Choose the Menu

- Press , it can choose menu block or options one by one.


Enter the Selected Menu

- Press , it can confirm which will be shown displayed.

Enter in to TECH

- When display showed `Pi n`, press   and  keys to enter the function

Escape from the Menu






- Press  key, it can escape from the menu to weighing mode.

| Menu | Sub Menu | Description | |
|--------|--|----------------------------------|--|
| F1 unt | ct / lb / oz / d /gn/ ozt / dwt / mom / tl.T / tlj /tlh/ t / bt / n | To select weighing unit on / off | |
| F 2 bl | El au | To set back light automatic on | |
| | El on | To set back light always on | |
| | El off | To set back light always off | |
| F3 com | Select first RS 232 or USB | | |
| | S 23 2 | P prt | By pressing Print key , weighing value will be added to the memory and print the print out |
| | | P cont | Send data continuous |
| | S usb | P auto | Automatic accumulation. Individual weighing values are automatically added |
| | | P ask | ASK mode Command R: read data Command T: Tare Command Z: Zero |







IHB++ Series Technical Manual

| | | |
|----------|--|---|
| | | |
| | <p>Set BAUD rate After setting the RS 232 mode, display will be shown current baud rate b XXX. Baud rate Options: b600, b1200, b2400, b4800 and b9600</p> | |
| | <p>Set Printer type After setting BAUD rate display will be show the printer type</p> | |
| | Lp 50 | Label Printer |
| | Tp | Ticket Printer |
| | <p>Set Language After setting Printer type display will be show the Language When select the TP printer, don't show language</p> | |
| | Eng | English |
| | chi | Chinese |
| F4 acc | Acc on | Accumulation function enable |
| | Acc of | Accumulation function disable |
| tech | pin | Enter the password |
| P 1 lin | | Linear Calibration |
| P 2 Cal | | Normal Calibration |
| P 3 cnt | xxxx | This display will show XXXXX for indicating the internal counts |
| P 4 a 2n | A2 off | To set to disable auto zero function |
| | A2 0.5d | To select the auto zero ranges |
| | A2 1d | |
| | A2 2d | |
| | As 4d | |
| P 5 gra | XXXXX | To set local gravity |
| P6 cap | 120g / 10000 g | To set Capacity (Optional) |
| P7 SPD | SPD 1 | To set AD speed |
| | SPD 2 | |
| | SPD 3 | |
| | SPD 4 | |
| P8 ical | ICAL OF | To set automatic calibration by built-in weight |
| | ICAL ON | |
| P9 hour | Off | To set timing calibration time |
| | 1 hour | |
| | 2 hour | |
| | 3 hour | |
| | 4 hour | |
| | 5 hour | |
| | 6 hour | |
| | 7 hour | |
| 8 hour | | |

8. CALIBRATION

- Turn on the scale.
- Press  key during self checking, display will be show `f 1 unt`
- Press  key until display will be show `tech`
- **Note: Before enter the tech menu, press calibration switch, which is locating below the scale**
- Press   and  keys, display will be show `p 1 lin`

8.1 Linear Calibration `li near`

- Press  key to enter calibration, display will be shown `pi n`
- Press   and  keys, display will be show `kg or lb`, press  key to select the calibration unit kilograms or pounds, press  key ,display will be show `Load0`.
- ***Note: Ensure the pan is empty**
- After stable and zero indicator on, display will be show `Load1`
- Place the first calibration mass weight on the pan.
- After stable and zero indicator on, display will be show `Load 2`
- Add again the second calibration mass weight on the pan.
- After stable and zero indicator on, display will be show `Load 3`
- Add again the third calibration mass weight on the pan.
- After stable and zero indicator on, display will be show `Load 4`
- Add again the fourth calibration mass weight on the pan, (***Note: Calibration mass weight should be full capacity of the scale**)
- After stable and zero indicator on, display will be show `load 0` Remove the calibration mass weight from the pan
- ***Note: Ensure the pan is empty**
- After stable and zero indicator on, display will be show `Load 4`
- Place the calibration mass weight on the pan, (***Note: Calibration mass weight should be full capacity of the scale**)
- After stable and zero indicator on, display will be show `Load 3`
- Remove the fourth calibration mass weight from the pan




- After stable and zero indicator on, display will be show Load 2
- Remove the third calibration mass weight from the pan
- After stable and zero indicator on, display will be show Load1
- Remove the second calibration mass weight from the pan
- After stable and zero indicator on, display will be show load 0 Remove the first calibration mass weight from the pan (***Note: Ensure the pan is empty**)
- After stable and zero indicator on, display will be will be start self checking. After self checking display will come to normal weighing mode

***Note:**

During the linear calibration steps LOAD 1 to LOAD 4, mass weights want to add on the pan. Don't remove all mass weights for the next step.


During the linear calibration steps LOAD 4 to LOAD 1, mass weights want to reduce from the pan. Don't remove all mass weights for the next step.

8.2 Normal calibration p2 cal



- Press  key to enter calibration, display will be show kg or lb, press  key to select the calibration unit kilograms or pounds, press  key ,display will be show unLoad.
- Remove all the weight from the platform.
- When scale get stable,display will be show load
- Place the calibration weight (1/3 of the capacity) on the platform
- After stable, scale will be calibrate automatically and will start self-test.

Note: Incase display will show any error message or incorrect measurement, repeat the calibration again.

8.3 Manual calibration by built-in weight

In the weighing mode, press and hold  key 3 seconds. The display will be show XCALX , after 20 seconds, the display will be show PASS and come back to the weighing mode.

8.4 Check internal counts F3 CNT

Press  key to enter internal counts, the display will be show “ XXXXX ”. Press  key to escape from the menu.

9. RS232 OUTPUT

9.1 Specifications:

RS-232 output of weighing data
 ASCII code
 600~9600 Baud
 8 data bits
 No Parity

9.2 Continuously output protocol



HEADER1: ST=STABLE, US=UNSTABLE
 HEADER2: NT=NET, GS=GROSS

9.3 Print Format

| Printer Mode | LP-50 (OS-2130D) | TP |
|-----------------|---|---|
| Weighing | 2013/07/05 12:00 S/NO: 1 WEIGHT: 200.000g | NO: 1 WEIGHT: 200.000g |
| Counting | 2013/07/05 12:00 COUNT: 250 pcs UNIT WT: 0.99998 g WEIGHT: 249.998 g | COUNT: 250 pcs UNIT WT: 0.99998 g WEIGHT: 249.998 g |
| Percent | 2013/07/05 12:00 PERCENT: 100.00% | PERCENT: 100.00% |